


Jumbo Beech Yarn Winder



Parts and Accessories

A – Winding Post

B – Yarn Guide

C – Spindle Support

D – Clamp


E – Oil

F – Yarn Guide Support

G – Guide Support Screw

H – Allen Key


I – Drive Band



ASSEMBLY INSTRUCTIONS




1) Unpack winder from box, and remove all plastic wrap.



2) Using Allen Key (H), loosen Spindle Support (C) and remove it.



3) Apply 2 drops of oil to metal bearing, then place Spindle Support (C) back on post and tighten it.



4) Place one end of Drive Band (I) around bottom of Spindle, ensuring it rests in the groove around the middle.



5) Place other end of Drive Band (I) around handle of the winder, ensuring it rests in the groove around the middle.



6) Lift entire spindle mechanism upwards, so that there is no gap between the Spindle and the Spindle Support (C). Hold in place.



7) Place Winding Post (A) onto the metal post pointing up from the Spindle, ensuring it rests snugly against the Spindle Support (C).



8) Fit Yarn Guide Support (F) to the notch in the base of the winder, ensuring the side that has a threaded hole sticks outward.



9) Secure Yarn Guide Support (F) to the base of the winder using the Guide Support Screw (G).



10) Screw Yarn Guide (B) into the threaded hole on the Yarn Guide Support (F), ensuring it is firmly in place – **DO NOT** tighten this area with tools of any sort.



11) For left-handed use, clamp the winder to a table with the handle towards the left, ensuring clamp rests in the groove on the base.



12) For right-handed use, clamp the winder to a table with the handle towards the right, ensuring clamp rests in the groove on the base.